



www.rustoleum.com

11 Hawthorn Pkwy., Vernon Hills, IL 60061 1-877-815-2536



PRE-PAINT CLEANER TSP SUBSTITUTE

Directions for Use:

1. Always pre-test before use.
2. Do not dilute. Use full strength.
3. Pre-moisten rag, cloth, or sponge with Prepaint Cleaner.
4. Spray directly on surface, and blot away any overspray immediately.
5. Apply pre-moistened cloth to surface in a circular motion.
6. Wipe off with a clean cloth, turning often to avoid smears.
7. When the clean, deglossed surface is dry to the touch (usually about 10 minutes), new paint finish can be applied.
8. Repaint when dry, or within a week, before soiled again.

If you have any questions or concerns regarding this product please contact Krud Kutter customer support at (800) 466-7126