

www.rustoleum.com
11 Hawthorn Pkwy., Vernon Hills, IL 60061 1-877-815-2536



AUTOMOTIVE UNIVERSAL BONDING PRIMER APPLICATION INSTRUCTIONS

PAINTING CONDITIONS

Use outdoors or in a well ventilated area such as an open garage. Use when temperature is between 50-90°F (10- 32°C) and humidity is below 85% to ensure proper drying. Do not apply to surfaces that, when heated, exceed 200°F (93°C). Avoid spraying in very windy and dusty conditions. Cover surrounding area to protect from spray mist.

SURFACE PREPARATION

Clean with soap and water, rinse and let dry. Remove all oil, grease, wax and petroleum based materials with mineral spirits. Remove loose paint and rust with a wire brush or sandpaper. Lightly sand glossy surfaces.

WARNING: If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find



www.rustoleum.com

11 Hawthorn Pkwy., Vernon Hills, IL 60061 1-877-815-2536 out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead•

APPLICATION

Shake can vigorously for one minute after the mixing ball begins to rattle. If mixing ball fails to rattle DO NOT STRIKE CAN. Contact Rust-Oleum. Shake often during use. Hold can 12" from surface and spray in a steady back-and-forth motion, slightly overlapping each stroke. Keep the can the same distance from the surface and in motion while spraying. Apply 2 or more light coats a few minutes apart. Do not use near open flame.

DRY & RECOAT

Dry and recoat times are based on 70°F (21°C) and 50% relative humidity. Allow more time at cooler temperatures. Dries to the touch in 30 minutes and dries to handle in 1 hour. Apply a second coat or topcoat at anytime. For two part epoxies, wait two hours before topcoating.

CLEAN-UP

Wipe off tip when finished. Clean up wet paint with xylene or mineral spirits. Properly discard empty container. Do not burn or place in home trash compactor.

CLOGGING

If the valve clogs, twist and pull off spray tip and rinse in a solvent such as mineral spirits. Do not insert any object into can valve opening.