



Application Instructions for Rust-oleum® Clear Finish Floor Topcoat

APPLICATION: RUST-OLEUM® CLEAR FINISH FLOOR TOPCOAT is ready to use. Do not thin. If using more than one gallon, intermix all cans of the same product to ensure gloss uniformity. Stir thoroughly before applying. Note: Painted floors may be slippery when wet. If desired, mix in **RUST-OLEUM® ANTI-SKID ADDITIVE** (sold separately). Use a brush or edger to trim the perimeter and hard-to-reach areas. Use a long handled roller and a high-quality, 3/8" nap roller cover to apply an even coat of **RUST-OLEUM® CLEAR FINISH FLOOR TOPCOAT** onto the surface. Apply in 4'x4' sections, and maintain a wet edge to prevent lap marks and gloss differences. Continue applying in 4'x4' sections until complete. Only one coat is necessary. If a second coat is desired, wait 4 hours before applying the second coat in a direction perpendicular to the first. Occasional touch-up may be necessary for areas subject to heavy vehicle traffic.

DRY TIME: Surface should be ready for light foot traffic in 24 hours. FOR FULL CURE AND VEHICLE TRAFFIC, ALLOW 5 DAYS. Dry times increase at cooler temperatures.

CLEAN UP: Wash tools and equipment with warm water and a mild detergent. Properly dispose of all soiled rags and protect unused product from freezing.