

USING CABINET TRANSFORMATIONS® COMPLETE COATING KIT

IDEAL FOR Kitchens or bathroom cabinets, furniture and more	KIT COVERAGE 100 square feet or 40 linear feet
USE Interior	FULL USE READY 24 hours after Protective Top Coat application
ADHERES TO Wood, Laminate, Melamine or Metal Surfaces <small>(See instructions for use on unfinished wood)</small>	CLEAN UP Soap and Water

COMPLETE COATING KIT INCLUDES	OTHER SUPPLIES NEEDED (not included in kit)
<input type="checkbox"/> Deglosser <input type="checkbox"/> Bond Coat <input type="checkbox"/> Decorative Glaze <input type="checkbox"/> Protective Top Coat	<input type="checkbox"/> (3) 2" Synthetic brushes <input type="checkbox"/> (3) Disposable paint containers <input type="checkbox"/> Smooth painter's tape (2" size) <input type="checkbox"/> Zinsser® Cover Stain® <input type="checkbox"/> Drop cloths <input type="checkbox"/> Disposable gloves <input type="checkbox"/> Lint-free rags

*To prevent discoloration that may occur to the painted surface when using Pure White, Linen, or Frost from severely worn or bare oak.

CALCULATING COVERAGE

Detailed step-by-step measuring instructions are included inside. Please be sure to validate your complete coverage area and confirm how many kits you will need before starting your project. Visit rustoleum.com/transformations for how-to videos and cabinet calculator guide.

LINEAR FEET – FOR QUICKLY ESTIMATING COVERAGE

STEP 1: Measure the length of your top and bottom cabinets (A + B + C + D = linear feet). Each kit includes enough coating to cover 40 linear feet of cabinetry with 2 exterior coats & 2 coats on the interior of each door and drawer face. Linear feet based on average height of standard wall and base cabinets being no more than 34-1/2".

SQUARE FEET – FOR CALCULATING EXACT COVERAGE NEEDS

STEP 1: Measure the length of your top cabinets (A + B) in inches and multiply times the height (E). Standard wall cabinet heights are: 12" - 18" and 30" - 42".

STEP 2: Measure the length of your bottom cabinets in inches (C + D) and multiply times the height (F). Standard base cabinet height is 34-1/2".

STEP 3: Add these two totals together and divide by 144 to determine the total square feet you will need to cover. Each kit includes enough coating to cover 100 square feet of cabinetry with 2 exterior coats & 2 coats on the interior of each door and drawer face.

SATISFACTION GUARANTEE: If you are dissatisfied with this product, contact Rust-Oleum Product Support at 800-901-0411 for product replacement or a full refund of the purchase price. Refer to product number and batch code.

WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov. Category Fax Finish: Max VOC <350 g/l

RUST-OLEUM CORPORATION
11 Hawthorn Place, Westport, N.Y. 10881
800-901-0411 rustoleum.com/transformations
Made in USA | Hecho en E.U.A.
©2018 Rust-Oleum Corporation. 34CT18 0018

LIGHT KIT 258109

TRUSTED QUALITY SINCE 1921

RUST-OLEUM® Cabinet Transformations®

100% SATISFACTION GUARANTEED

EASY 3-STEP APPLICATION

STEP 1: DEGLOSSER

- Apply Deglosser with scrub pad (included) to remove grease, oil and dirt.
- Prepares surface without stripping, sanding or priming*

STEP 2: BOND COAT

- Brush on two smooth, even coats of the Bond Coat
- Engineered to provide ultimate adhesion and color retention
- Formulated to resist scuffing, cracking, chipping and peeling

(OPTIONAL) DECORATIVE GLAZE

- Brush on and wipe off with glazing cloth (included) to achieve your desired effect
- Get the look you want – more glazing techniques available at rustoleum.com/transformations

STEP 3: PROTECTIVE TOP COAT

- Apply one coat using long, smooth strokes
- Durable finish provides superior stain and scratch resistance
- Crystal clear, non-yellowing, low odor, satin finish

*In rare instances on severely worn or bare oak, some discoloration may occur to the painted surface when using Pure White, Linen or Frost. To prevent this from happening, prime first with an oil-based stain blocking primer such as Zinsser® Cover Stain®.

TRUSTED QUALITY SINCE 1921

RUST-OLEUM® Cabinet Transformations®

COVERS UP TO 100 SQ. FT. OR 40 LINEAR FT.

TINT TO 1 OF 11 COLORS SEE TOP COLOR SELECTION

COMPLETE COATING KIT

Transform the Look of Outdated Cabinets

NO STRIPPING, SANDING, PRIMING

BEFORE AFTER

EASY 3-STEP APPLICATION | MAXIMUM SCRATCH & STAIN RESISTANCE | SOAP & WATER CLEAN UP | FULL USE AFTER 24 HOURS

1 Deglosser (32 fl oz) (946 mL), 2 Bond Coat (28.5 fl oz) (946 mL)
1 Top Coat (32 fl oz) (946 mL), 2 Glaze (8 fl oz) (237 mL)

LIGHT TINT BASE

CAUTION! This kit contains the following chemicals that may be harmful if misused: Glycol Ethers and Alcohols. Read cautions on individual containers carefully. KEEP OUT OF REACH OF CHILDREN.

TRUSTED QUALITY SINCE 1921

RUST-OLEUM® Cabinet Transformations®

Transform your cabinetry, vanity, furniture and more with beautiful results. Can be used on wood, laminate, melamine or metal surfaces.

BEAUTIFUL RESULTS

Instantly Refresh and Renew Cabinets at a Fraction of Cost of Replacing	No Remodeling or Messy Demolition	Create the Look of Handcrafted Cabinets	Optional Decorative Glaze Lets You Create Your Custom Look	Durable Top Coat Provides a Long-lasting Finish
---	-----------------------------------	---	--	---

LIGHT TINT BASE

TINT TO THE COLOR OF YOUR CHOICE
Pick from a variety of colors to complement your project and bring to the paint counter for tinting

BOND COAT MUST BE TINTED AT STORE

Pure White*	Linen*	Frost*	Quilter's White
French Cream	Winter Fog	Iced Gray	Smokey Beige
Stone Gray	Cadet Gray	Greige	

WITHOUT DECORATIVE GLAZE
WITH DECORATIVE GLAZE

Optional Decorative Glaze (included in this kit) lets you enhance the natural beauty of the wood grain.
Actual colors shown may vary slightly due to lighting, printing process or surface conditions.

*In rare instances on severely worn or bare oak, some discoloration may occur to the painted surface when using Pure White, Linen or Frost. To prevent this from happening, prime first with an oil-based stain blocking primer such as Zinsser® Cover Stain®.