



Rust-Oleum Clear Shimmer Floor Topcoat Application Instructions

- **RUST-OLEUM® CLEAR SHIMMER FLOOR TOPCOAT** is ready to use.
- Do not thin.
- If using more than one gallon, intermix all cans of the same product to ensure gloss uniformity. Stir thoroughly before applying.
- Note: Painted floors may be slippery when wet.
- If desired, mix in **RUST-OLEUM® ANTI-SKID ADDITIVE** (sold separately).

Use a brush or edger to trim the perimeter and hard-to-reach areas. Use a long handled roller and a high-quality, 3/8" nap roller cover to apply an even coat of **RUST-OLEUM® CLEAR SHIMMER FLOOR TOPCOAT** onto the surface. Apply in 4'x4' sections, and maintain a wet edge to prevent lap marks and gloss differences. Continue applying in 4'x4' sections until complete. Only one coat is necessary. If a second coat is desired, wait 4 hours before applying the second coat in a direction perpendicular to the first. Occasional touch-up may be necessary for areas subject to heavy vehicle traffic.

DRY TIME: Surface should be ready for light foot traffic in 24 hours. FOR FULL CURE AND VEHICLE TRAFFIC, ALLOW 5 DAYS. Dry times increase at cooler temperatures.

CLEAN UP: Wash tools and equipment with warm water and a mild detergent. Properly dispose of all soiled rags and protect unused product from freezing.