

www.rustoleum.com

11 Hawthorn Pkwy., Vernon Hills, IL 60061 1-877-815-2536





ADHESIVE REMOVER

Directions for Use:

- 1. Always test on inconspicuous area first.
- 2. Saturate the adhesive by applying a liberal amount directly onto the finish.
- 3. Allow time for the remover to work. It will loosen most finishes in 15-30 minutes.
- 4. Test scrape a small area to see if finish is ready for removal.
- 5. Scrape away the softened adhesive with a wide putty knife or scraper.
- 6. Multiple coats or stubborn finishes may require repeat applications.
- 7. For final clean-up, apply onto the surface and wipe clean.
- 8. Before installing new floor covering, allow surface to dry for 1 hour or more.