

6x DECK REFINISH



QUICK REFERENCE INSTALL GUIDE

1 MIX COATING MATERIALS



Combine dry mixture, tint and 32 oz. of cool, clean water in bucket. Mix with supplied mixing fork. Then allow product to sit for 30 minutes. See induction time on back side under mixing instructions for more information.

2 APPLY TO VERTICALS (OPTIONAL)



Use a brush or roller to apply to vertical surfaces. Vertical surfaces require only one coat.

3 PRECONDITIONING



'Wet-out' your wood surface to ensure maximum spread rates while coating. Keep wood moist during application, but do not spray water on applied product. Avoid standing water. Skip this step if priming with RockSolid® Deck Start Wood Primer.

4 CUT IN EDGES



Cut in the edges and cracks with a paint brush.

5 ROLL OUT COATING



Apply the coating with tray and 3/8" nap roller. Each kit covers 100 square feet with two coats.

