



www.rustoleum.com

11 Hawthorn Pkwy., Vernon Hills, IL 60061 1-877-815-2536



## Specialty Tub & Tile Kit Tips & Techniques

- Preparation is key, be sure to prep the roller by removing loose fibers. This can be done by wrapping the roller with painter's tape and removing the tape to pull off any excess material.
- Like all projects, it is good to test in a small, hidden area before painting to test adhesion and appearance.
- By patching and repairing all cracks prior to Tub & Tile application your project has the preparation needed for a fresh finish.
- Be sure to use Tub & Tile within 6 hours of mixing both Part A and Part B together.