



**ZINSSER®
FURNITURE REFINISHER**

DESCRIPTION AND USES

Zinsser® Furniture Refinisher is designed to remove clear finishes, dirt, grime, lacquer, shellac, varnish and wax in one application. Use on antique furniture, fine wood and cabinets. Just wipe on, then wipe away old finish.

PERFORMANCE CHARACTERISTICS

- Clings to round and vertical surfaces
- Works in 20-30 minutes
- Excellent for wood, metal and masonry

PRODUCTS

SKU	Description
42141	1-Gallon
42144	1-Quart

PRODUCT APPLICATION

SURFACE PREPARATION

Spread a solvent resistant drop cloth covered with newspapers around the work area in case of drips and spills. Protect eyes and skin. Wear safety goggles and chemical resistant gloves. Keep away from heat, sparks and flames.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. **LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE.** Wear a NIOSH-Approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

PRODUCT APPLICATION (cont.)

APPLICATION

USE ONLY WITH ADEQUATE VENTILATION. Apply only when air and surface temperatures are between 65-90°F (18-32°C) and the relative humidity is below 85%. Shake can before using and open can carefully to relieve pressure. Pour Furniture Refinisher into a glass or metal container. Use steel wool to apply. Saturate steel wool in refinisher and squeeze out excess. Rub steel wool in a circular motion, working an area approximately 1 foot in diameter. Rinse and squeeze steel wool often while continuing to work until old finish is dissolved. Move on to an adjacent area of equal size and repeat the process, overlapping each area until the entire piece is clean. The process may be stopped at any time without damage or waste and resumed at your convenience. Use a clean piece of steel wool dipped in fresh Furniture Refinisher and wipe with long even strokes following the grain to remove lap marks. Allow 30 minutes to dry, then buff thoroughly with a clean, dry pad of steel wool. There is no need to clean with other chemicals.

SPILLAGE

Open containers carefully and close after each use. If spilled, contain spilled material and remove with an inert absorbent. Dispose of contaminated absorbent, container and unused contents in accordance with local, state and federal regulations. Clean up rags, papers and waste promptly.

CLEAN-UP

Clean up tools and brushes with soap and water.



TECHNICAL DATA

ZINSSER® FURNITURE REFINISHER

PHYSICAL PROPERTIES

Physical Properties		FURNITURE REFINISHER
Composition		Acetone, Methanol, Toluene
Weight	Per Gallon	6.7 lbs.
	Per Liter	0.80 kg
Volatile Organic Compounds		822 g/l
Practical Coverage		Varies with thickness and type of coating
Shelf Life		5 years
Flash Point		-4°F (-20°C)
Caution!		Cannot be made non-poisonous. Do not get in eyes, on skin or clothing. Causes skin, nose and throat irritation. May be harmful if absorbed through skin. Wash thoroughly after handling. KEEP OUT OF REACH OF CHILDREN.
Safety Information		For additional information, see SDS

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.