SUREGRIP® 132 KITCHEN & BATH WALLCOVERING ADHESIVE

DESCRIPTION AND USES

Rust-Oleum® SureGrip® 132 Kitchen & Bath Adhesive is a ready-to-use, mildew-resistant adhesive for hanging pre-pasted and non-pasted wallpaper in high humidity areas like kitchens, baths or laundry rooms. It has excellent adhesion to help stop curling edges and lifting seams common in moisture-prone environments. It is non-staining, strippable and dries clear.

SureGrip 132 Kitchen & Bath Adhesive is not recommended for hanging pre-pasted or non-pasted borders or wallcovering over existing wallcoverings. See "Existing Vinyl Wallcovering" under Application in next column for recommendations.

PERFORMANCE CHARACTERISTICS

- For pre-pasted and non-pasted wallpaper
- Stops curling edges and lifting seams
- Mildew resistant adhesive for humid areas
- Strippable
- Dries clear

PRODUCTS

SKU	Container Size
69990	1-Gallon

PRODUCT APPLICATION

SURFACE PREPARATION

Surfaces must be clean, dry, sound and free of dust, grease, wax, oil, old wallcovering adhesive, mold and mildew and other residue. Inspect the surface for paint bonding, loose wallcoverings, damaged wallboard or plaster. Remove old or loose wallcovering and residual wallcovering adhesive with DIF® Wallpaper Stripper. Repair unsound surfaces. Seal loose paint or damaged drywall and cured skim coats with Gardz® High Performance Sealer as needed.

PRODUCT APPLICATION (cont.)

Prime all surfaces (including oil-based paints, oil-based primers or oil-based stain-kill coatings) with ShieldZ® Universal, ShieldZ® Universal Plus, ShieldZ Clear Acrylic Wall Size or ShieldZ Oil-Base Wallcovering Primer.

Mold & Mildew

Eliminate pre-existing mold and mildew by washing the affected area with a solution of ¾ cup of bleach to 1 gallon of water. Wear protection to prevent skin and eye contact. Quickly wash off any solution that comes in contact with your skin. Do not add ammonia or other cleaning agents to the bleach solution. Rinse surface with clean water. Allow surface to dry thoroughly before applying wallcovering.

Drywall

Wipe down with a damp cloth to remove residual joint compound dust prior to priming.

Plaster

New plaster must age at least 90 days before hanging wallcovering. Prime prior to installation.

Glossy Surfaces

Glossy paint, paneling, metal, glass, plastic, etc. should be primed with ShieldZ Universal, ShieldZ Universal Plus, ShieldZ Clear Acrylic Wall Size or ShieldZ Oil-Base Wallcovering Primer prior to wallcovering installation. Metal surfaces should be primed with rust inhibiting Bulls- Eye® 1-2-3 Primer.

Existing Vinyl Wallcovering

This product is not intended for hanging borders or wallcovering over existing wallcoverings. Use either SureGrip Universal Adhesive, SureGrip Border Adhesive for Wallpapered Surfaces ore SureGrip 127 Vinyl over Vinyl Wallcovering Adhesive.

Textile/Delicate/Polyolefin/Polyester Backed Wallcoverings

Take special care to keep the adhesive off the face of textile or delicate wallcovering. Some wallcovering can be stained by water alone. Test for stain resistance prior to installation and hang according to manufacturer's instructions.

PRODUCT APPLICATION (cont.)

APPLICATION

Use only when temperature is between 50-100°F (10-38°C) and the relative humidity is less than 85%. Adhesive is ready-to-use. DO NOT DILUTE. Apply an even coat using a brush, roller or pasting machine. Make sure sufficient adhesive is on edges. Make sure sufficient adhesive is on edges. Avoid contact with the surface of embossed or delicate wallcovering. Book and hang wallcovering according to the manufacturer's instructions.

COVERAGE

One gallon of adhesive will hang up to 4 to 5 double rolls of 250 square feet. Spread rate may differ with various wallcoverings.

DRY TIME

Drying time will vary depending on the wallcovering type, temperature, ventilation and humidity in the room.

CLEAN-UP

Remove excess adhesive on or around the wallcovering immediately with clean water. Additional effort may be required if adhesive is allowed to contact the surface of embossed or textured vinyl. Close container tightly after each use.

TOOL CLEAN-UP

Clean tools with warm water.

STORAGE

Protect from freezing. Always keep the container tightly closed and store in a cool dry place at temperatures between 40-100°F (4-38°C).

TECHNICAL DATA

SUREGRIP® 132 KITCHEN & BATH ADHESIVE

PHYSICAL PROPERTIES

	SureGrip 132 Kitchen & Bath Adhesive
Resin Type	Synthetic Polymer Based Adhesive
Solvents	Water
Appearance	Clear
Odor	Mild
Solids by Weight	17.4-19.4%
Volatile Organic Compounds (when mixed with water)	<10 g/l (0.083 lbs./gal.)
Practical Coverage at Recommended DFT (assumes 15% material loss)	250 sq.ft./gal. May vary depending on porosity and application method.
Dry Times at 70-80°F (21-27ºC) and 50% Relative Humidity	Drying time will vary depending on the wallcovering type, temperature, ventilation and humidity in the room.
Shelf Life	1 year
Flammability	Non-flammable
Safety	For additional information, see MSDS
NOTE:	Calculated values may vary slightly from the actual manufactured material.

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.

RUST-OLEUM BRANDS

Rust-Oleum Corporation
11 Hawthorn Parkway
Vernon Hills, Illinois 60061
An RPM Company

Phone: 877•385•8155
www.rustoleum.com

Form: GDH-134
Rev.: 080113